




Lenovo Yoga 3 Pro Battery Replacement

This guide will show you how to access and remove the battery.

Written By: Federico LopezCasildo Jr



INTRODUCTION


After a certain period of time or number of uses, a battery loses how long it can stay alive after a single charge. This guide will aid a user in removing the back panel in order to be able to reach and securely remove the battery so as to replace it.




TOOLS:

- [Phillips #00 Screwdriver](#) (1)
 - [T5 Torx Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Battery




 Before opening your laptop, make sure it is powered off.

- Remove the ten 3.3 mm screws from the base cover using the T5 Torx screwdriver.

Step 2




- Slide the plastic opening tool between the base cover and the frame to pry open the computer.
- Slowly go around the entire perimeter of the computer until all edges are loose.
-  Make sure the plastic opening tool doesn't go too far into the device.

Step 3




- Remove the panel and place it in a safe location.

Step 4



- Remove the six 3.5 mm screws surrounding the battery using the Phillips 00 screwdriver.

Step 5



- Remove the battery.

❗ It is helpful to lift and hold the battery as shown and wiggle it out from the connector.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 10:42:41 PM.